

The method

1. Lay the first course on a traditional sand-cement mortar bed
2. Ensure the first blocks are level, horizontal in both directions and vertically plumb. This is the most crucial stage of the process, as it determines the levelness of each of the subsequent build storeys, and the speed and accuracy of the construction as a whole
3. Mix ZeroPlus according to guideline quantities – don't mix more than you need
4. Apply ZeroPlus (mixed close to the build) to blocks with a roller
5. Repeat until a precision wall is complete – up to four times faster than traditional methods
6. Wall ties are easily installed
7. Insulation can be applied simply
8. Block-cutting is straightforward

